




how to fold your echo glow hoop





- 1. unclip the connector using the button spring
- 2. bend the hoop into a smaller loop until it meets again as shown

3. once the hoop is doubled over, reconnect the button spring to the first hole to keep it in position



do NOT partially unclip and twist the hoop as you might a regular travel hoop, as this can damage the sensitive internal components of the

LED hoop

